Coast Guard, DHS §117.849

restore constant attendance when so directed by the District Commander.

§117.833 Pasquotank River.

- (a) The draw of the Albemarle & Chesapeake railroad bridge, mile 47.7, at Elizabeth City, North Carolina, shall be maintained in the open position; the draw may close only for the crossing of trains and maintenance of the bridge. When the draw is closed, a bridgetender shall be present to reopen the draw after the train has cleared the bridge.
- (b) The draw of the US 158 Highway Bridge, mile 50.7, at Elizabeth City, shall open on signal; except that between 7 a.m. and 9 a.m., and 4 p.m. and 6 p.m., Monday through Friday, the draw need open only at 7:30 a.m., 8:30 a.m., 4:30 p.m., and 5:30 p.m. for any pleasure vessels waiting to pass.

[CGD05-94-118, 60 FR 40098, Aug. 7, 1995, as amended by CGD05-97-009, 62 FR 66006, Dec. 17, 1997]

§117.835 Perquimans River.

The draw of the US17 bridge, mile 12.0 at Hertford, shall open on signal from 8 a.m. to midnight from April 1 through September 30 and from 10 a.m. to 10 p.m. from October 1 through March 31. The draw need not be opened at all other times.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984; 49 FR 37382, Sept. 24, 1984]

§117.837 Roanoke River.

The draw of the Seaboard System Railroad bridge, mile 94.0 at Palmyra, need not be opened for the passage of vessels.

 $[{\rm CGD5\text{--}92\text{--}004,\ 57\ FR\ 11580,\ Apr.\ 6,\ 1992}]$

§117.841 Smith Creek.

The draw of the S117-S133 Bridge, mile 1.5 at Wilmington, need not open for the passage of vessels.

[USCG-2008-0302, 73 FR 46194, Aug. 8, 2008]

§117.843 Trent River.

- (a) The draw of the U.S. 70 bridge, mile 0.0, at New Bern:
- (1) Need not open from 6:30 a.m. to 8:30 a.m. and from 4:00 p.m. to 6:00 p.m., Monday through Friday, for pleasure vessels. However, the draw shall open

at 7:30 a.m. and 5:00 p.m. for any vessel waiting to pass.

- (2) Need not open from 2:00 p.m. to 7:00 p.m. from May 24 through September 8, on Sundays and Federal holidays, for pleasure vessels. However, the draw shall open at 4:00 p.m. and 6:00 p.m. for any vessel waiting to pass.
- (3) Must always open on signal for public vessels of the United States.
- (4) Shall open on signal at all other times.
- (b) The draws of the Seaboard System Railroad bridge, mile 18.0 near Pollocksville, need not be opened for the passage of vessels.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984, as amended by CGD5-88-53, 54 FR 1361, Jan. 13, 1989; USCG-2001-10881, 71 FR 70312, Dec. 4, 20061

Оню

§117.847 Ashtabula River.

- (a) The draw of the Fifth Street bridge, mile 1.4 at Ashtabula, shall open on signal for the passage of commercial and emergency vessels and on the hour and half hour for all other vessels.
- (b) The draw of the Norfolk Southern Bridge, mile 1.5 at Ashtabula, is remotely operated, is required to operate a radiotelephone, and shall open on signal from April 1 through November 30 from 7 a.m. to 11 p.m. At all other times the draw shall open on signal if at least 24 hours notice is given.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984, as amended by USCG-1999-5832, 64 FR 34712, June 29, 1999; USCG-2009-0968, 74 FR 63612, Dec. 4, 2009]

§ 117.849 Muskingum River (Zanesville Canal).

The draw of the Conrail bridge, mile 77.1 at Zanesville, shall open on signal Tuesday through Friday if the Conrail office is notified by 12:01 p.m. on the day preceding the day the opening is required. For openings Saturday through Monday, the Conrail office shall be notified by 12:01 p.m. on Friday specifying which day and time the opening is required. In case of emergency, the draw shall open as soon as possible.